

※ Please be sure to follow the cautions below when using this product ※


○ This product assumes transportation will be over flat, hard floors.

Please do not move UFO-Insulators over a floor with varying level.

The UFO-Insulator will be damaged if used on uneven surfaces.


UFO-Insulator (For GP), Common points of both G-UFU-S/G-UFO-W

TOP



Stopper finger grips


※After taking the UFO Insulator out of its box, please raise the stoppers by using the finger grips.



Set up instructions


1

Lift the legs of the grand piano one by one and place the castors into the castor receivers correctly.




Please make sure the caster is installed in the caster receiver correctly.

2



Turn both finger grips (in 2 places) to fix the stopper.
※ Do not tighten too much.



※ Cautions when using ※

- When you move a grand piano, release the stoppers by using the finger grips to raise them to the top position.
- If you loosen the stopper grip too much, the bolt may come off. Please stop loosening the grip when it reaches to the top position.
- Please do not move a grand piano forcefully when the stopper is fixed. The stopper will be damaged or the floor will be damaged.